



NOTE: ENSURE POWDER COATING IS REMOVED FROM UNDERSIDE OF MOTOR MOUNT CHANNEL WHERE SOLENOID IS MOUNTED. ALSO, REMOVE POWDER COATING FROM INSIDE OF LARGE HOLES WHERE MOTORS ARE MOUNTED TO MOTOR MOUNT PLATES

RECOMMEND USING CONTINUOUS DUTY SOLENOID NAPA ST95 12V OR EQUIV.

SIMPLIFIED SCHEMATIC FOR TWD
 GENERIC (LESTER #3153 /3180 / 3186 or EQUIVALENT) FORD MOTOR

12 VOLT BATTERY WIRING DIAGRAM